


Heliflow Shaft Configuration Guide

The Heliflow Industrial Series features flex-mounting design to enable horizontal and vertical mounting configurations with the top or bottom hand, right or left hand shaft positioning. The units are discharge timed allowing rotation in only one direction.

Use the illustration below to select the required shaft configuration. Your blower will be shipped to you as specified in your order.

VERTICAL CONFIGURATION



HORIZONTAL CONFIGURATION

