



Duroflow 30&70 Series Configuration Guide

Use the illustration below to select the required shaft configuration for Duroflow 30 & 70 Series blowers. Your blower will be shipped to you as specified in your order.

30 SERIES



70 SERIES



SHAFT ROTATION KEY: CW = CLOCKWISE
CCW = COUNTERCLOCKWISE

NOTE: When changing configurations be sure to relocate Oil Fill, Oil Drain and Breather Filters into their proper position. 30 Series blowers require a mounting foot change with a configuration change. 70 Series blowers use the same mounting feet for all configurations.

Excelsior Blower Systems, Inc., 331 June Ave, Blandon, PA 19510

610-921-9558

www.excelsiorblower.com